

ROADRECORDER® 7006 USER GUIDE



Important Notices

Title: RoadRecorder 7006 NVR User Guide Firmware Version: 5.0.9 Document Version: 4 Revision: 3

Safety Vision attempts to provide information contained in this manual based on the latest product information available at the time of publication. However, because of Safety Vision's policy of continual product improvement, Safety Vision reserves the right to amend the information in this document at any time without prior notice.

This material is confidential and the property of Safety Vision. It is shared with your company for the sole purpose of helping you with the operation of the described equipment.

Safety Vision makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Safety Vision shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Safety Vision expressly disclaims all responsibility and liability for the installation, use, performance, maintenance, and support of third-party products. Customers are advised to make their independent evaluation of such products.

No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Safety Vision.

Safety Vision[®] is a registered trademark of Safety Vision, LLC. All other products or name brands mentioned in this document are trademarks of their respective owners. For more information about Safety Vision and its products, go to www.safetyvision.com or call 800-880-8855.

Contents

Components	3
Front Panel	3
Rear Panel	4
LCD Control Panel	5
50-00001	5
Installation	6
Main Wiring Diagram	6
Flat Mount	8
Air Filter Replacement	9
Video Retrieval	10
50-000001 LCD Control Panel	11
Configuration	12
Connecting to the NVR	12
Help Windows	13
Product Details	14
Live View	15
Snapshot Viewer	16
Video Out	17
Firmware/Config	18
Storage	19
Network Settings	20
Date / Time	21
Change Password	22
Startup & Shutdown	23
Audio/Video Settings	25
PoE Settings	27
Sensor Settings	28
Recording	30
Thresholds	31

	GPS / GEO Fence	32	
	Camera	33	
	Sensor Status	34	
	GPS Status	35	
	Recorder Status	36	
	Tag Events	37	
Арр	endix A: Specifications	38	
Арр	endix B: Dimensions	39	
Арр	endix C: Axis Device Configuration	40	
Арр	endix D: GPS Coordinate	41	
Con	version	41	

Components

Front Panel

1 - Status LEDs - See table at right.

2 - External GPS Input (top) - Connect the Garmin[®] GPS antenna (part number 333401). **DO NOT CONNECT TO A PC.**

3 - CANBUS (bottom) - Connect option CANBUS compatible accessories.

4 - USB Port (top) - USB 2.0. For firmware uploads and Service Technician use.

5 - USB Port (bottom) - USB 1.1. Connect the LCD Control Panel.

6 - LAN Ethernet (top) - Use an Ethernet cable to connect an external Wi-Fi bridge or a computer to access the configuration web server.

7 - EXT Port (bottom) - Use an Ethernet cable to connect a computer to access the configuration web server, or connect a PoE switch to add additional cameras.

8 - RS-485 - For future development.

9 - Micro USB - For Service Technician use only.

10 - Micro HDMI -Connect an optional external monitor to display live camera feeds. See the Firmware Settings section of the Configuration chapter for more information about the Mosaic function.

11 - Hard Drive Bay - Insert or remove the removable hard drive. See the Hard Drive section of the Video Retrieval chapter for more information.



LED	Color	Status
	Green	On : NVR is ready to record
		Blink: NVR Power on (startup) condition met
	Red	On : Vehicle power failure, in shutdown sequence
•		Blink: Shutdown condition met, shutting down
	Off	NVR shut down complete
	Green	On : All cameras initialized correctly and have video
		Blink: Camera initialization in progress
	Red	On : One or more cameras has video loss
		Blink: One or more camera initializations failed
	Green	Solid: GPS fix attained
	Orange	Blink: Searching for GPS signal
6	Red	Off: No GPS signal or error
	Green	On : NVR running and recording
		Blink: NVR running, but not recording currently
11	Red	On : One or more events have been recorded
U		Blink: NVR shutting down
	Off	NVR powered off
	Green	On : SSD OK (mounted) Blink : SSD activity
P	Orange	On: N/A
	Red	On : SSD error/failure/not present
	Off	SSD powered off

Note: SSD error/failure is detected when volume is mounted on SSD.

Rear Panel

1 - Sensor Inputs and Ignition and Relay

Outputs - See diagram below.

2 - Camera Ports - Camera inputs A1 through A6. Each input is power over Ethernet (POE) enabled.

3 - Air Filter Housing - Air intake that houses a replaceable air filter. See the Air Filter Replacement chapter for more information.



For further information regarding the configuration of the RoadRecorder 7006 NVR, see the Configuration chapter.

Sensor Inputs and Ignition and Relay Outputs

1 - Power, Ground, Ignition

2 - Sensor Inputs - Attach up to 7 sensor inputs with the approrpiate Phoenix connector.

3 - Relay Outputs - Attach relay outputs with the appropriate Phoenix connector.



LCD Control Panel

50-000001

The 50-000001 LCD Control Panel is designed to provide advanced functionality with the RoadRecorder 7006 NVR. See the *50-000001 LCD Control Panel* chapter for more information.

1 - LCD Display - Displays alerts and statuses.

2 - Esc Button - Press the Esc Button to cancel the current command a return to the display.

3 - Navigation Keys - Use the left, right, up, and down keys to navigate menus or move the cusor. Press the center key to enter a command.

4 - Event Button - Press the Event Button to save an event.

5 - Error Status LED - Displays solid red when an error has occured, such as a disconnected camera. The LED remains red until the error is corrected. Displays solid green when no errors are present.

6 - Event Status LED - Displays solid red when an event is recording. The LED remains red until recording is finished. Displays solid green otherwise.

7 - Offloading Status LED - Displays solid red when recorded data is being offloaded.



Installation

Main Wiring Diagram



Typical Configuration									
Sensor Wire	Color	Description							
A1	White	Main Power							
A2	Red	Main Power							
A3	Green	Ground							
A4	Black	Ground							
A5	Orange	Ignition							
A6	Blue	Brake							
A7	Yellow	Right Turn							
A8	Green	Left Turn							
A9	Red	Headlights							
B1	Brown	Front Door							
B2	White	Wheelchair							
B3	Black	Stop Request							
B4		Open							
B5		Open							
B6		Open							
B7		Open							
B8		Open							
B9		Open							
	Fuse Requirer	nents							
P1	Red	Main Power (7.5 amp)							
B1	Orange	Ignition (3 amp)							



WARNING: REMOVING MAIN THE MAIN POWER SOURCE WHILE THE NVR IS RECORDING MAY RESULT IN CORRUPT DATA.

Be aware that removing and reconnecting power to the NVR in short periods of time (such as during some vehicle maintenance procedures) may cause hard drive failure, leading to corrupt recorded video and other data. Safety Vision recommends properly shutting down the NVR before removing the main power harness when cycling of the vehicle's power is to occur:

- 1. Remove the ignition source.
- 2. Wait for the NVR to completely power down. The NVR may be configured to record for a period after the ignition is turned off. (Wait for the SafeStor process to complete [7000 model only]).
- 3. OBSERVE THAT ALL STATUS LEDS HAVE TURNED OFF.
- 4. Remove the main power harness.

Flat Mount

Secure the RoadRecorder 7006 NVR assembly to a secure flat surface with appropriate fasteners.

NOTE: Ensure that the front panel of the RoadRecorder 7006 NVR remains visible and accessible. Do not install the RoadRecorder 7006 NVR in an area of the vehicle cabin that could interfere with the safe operation of the vehicle.



Air Filter Replacement

The RoadRecorder 7006 NVR includes a replaceable air filter behind the rear air intake to protect the internal components from potential contaminates.

Use the following procedure to replace the air filter.

- 1. Remove the T10 security bit screw securing the filter housing to the front panel.
- 2. Pivot the filter housing out and to the left.
- 3. Inspect the filter medium and replace if dirty.
- 4. Holding the filter medium against the back panel as shown, insert the two tabs on the filter housing into the front panel and pivot it down.
- 5. Replace the T10 security bit screw to secure the air filter housing.



Video Retrieval

Use the following procedure to remove the hard drive.

- 1. Ensure the hard drive is not being accessed.
- 2. Insert the key as shown and turn it 90 degrees to the left.
- 3. Push the plunger to extend it.
- 4. Push the plunger again firmly to push the hard drive out.
- 5. Grasp the hard drive and pull it straight out.

Once removed, the hard drive can be read with the hard drive reader connected to a PC. The computer recognizes the hard drive as an external storage device. For more information, refer to the 7000 HDD Reader Quick Reference Guide.

Use the following procedure to reinsert the hard drive.

- 1. Push the hard drive straight into the RoadRecorder 7006 NVR firmly until it is fully seated.
- 2. Push the plunger back into its unextended state.
- 3. Turn the key 90 degrees to the right.
- 4. Remove the key.





50-000001 LCD Control Panel

The 50-0000001 LCD Control Panel provides advanced functionality from a remote location.

Nominally, the LCD Control Panel displays the NVR's name, date, and time (as entered in the Web Configuration) in addition to any active alarms, such as recording events or errors.

Creating Events

Press the Event Button to create an event. The LCD displays a confirmation and the Event status LED displays red until the event has finished recording. Events can be configured in the Firmware Settings page of the Web Configuration interface.

Main Menu

Press the center navigation key to display the Main Menu. There are four options available: System Details, System Logs, Manual Offload, Remove SSD, and Help. Use the arrow keys to move the cursor and to scroll up and down through items. Press the center navigation key to confirm or enter a command, and the **Esc** key to back out of a menu, or cancel.

System Details

Select System Details to display information about the firmware installed on the NVR. Firmware Version is the only available option.

Firmware Version

Select Firmware version to display the firmware version currently installed on the NVR. This information may be useful when speaking with Safety Vision Technical Support.

System Logs

Select System Logs to display a list of current and past events or errors.

Event Logs

Select Event Logs to display the most recent recorded event timestamps. Use the up and down navigation keys to scroll through the list of events.

Error Logs

Select Error Logs to display the most recent errors. The nature of the error and the time at which it occured are displayed. Use the up and down navigation keys to scroll through the list of errors.

System Logs are stored in the LCD Control Panel's internal memory. Disconnecting the LCD Control Panel from the NVR will result in the loss of data. (This data is still recorded by the NVR, but can no longer be displayed on the LCD.)



Manual Offload

Select the Manual Offload option to manually offload recorded events to a USB flash drive inserted in the front of the NVR.

Press the center navigation key to select **To USB**. Use the directional navigation keys to highlight the characters of the offload password (as configured in the Change Password configuration screen) and press the center navigation key to enter them.

Once finished, highlight Done and press the center navigation key to enter the password. Confirm event or continuous recording. When the offload is taking place, the bottom LED status light displays red. When the process it complete, the LED reverts to displaying green.

Remove SSD

Select the Remove SSD option from the main menu to remove the hard drive. Use the navigation key to highlight each character of the password and press the center navigation key to enter it. *Wait for the "Insert Storage Media" prompt appears BEFORE removing the hard drive.*

Help

Select the Help option to display a help message regarding manual offloads.

Configuration

The RoadRecorder 7006 NVR can be configured through the on-board web interface, which must be accessed with a PC and web browser.

Connecting to the NVR

Use the following procedure to access the configuration web server using the default IP address:

- 1. Connect the PC to the NVR's EXT port with a standard Ethernet cable.
- 2. Ensure the NVR and PC are receiving power and have started up.
- **3.** Open the Internet Protocol (TCP/IP) Properties window for the LAN connection you are using.

In Windows, open Network Connections. Right-click the LAN connection and select *Properties*. In the list of items, select *Internet Protocol (TCP/IP)* and then click *Properties*.

- 4. Select the Use the following IP address option.
- 5. Enter 182.168.1.80 in the IP address field.
- Enter 255.255.0.0 in the Subnet mask field.
 This field normally defaults to 255.255.255.0. Ensure the correct 255.255.0.0 subnet is entered.
- 7. Leave all other fields blank.
- 8. Click **OK** on the Internet Protocol (TCP/IP) Properties window and then click **OK** on the Local Area Connection Properties window.

Your PC's IP address and subnet mask are now configured.

9. On a web browser, navigate to 182.168.1.200.

The Login screen appears.

The default user name and password are "admin". If this has been changed, contact your system administrator for your login information.

10. Enter the user name and password and click Login.

The configuration web interface launches.

Access different pages of the web interface by clicking on the links on the left side of the screen.

ernet Protocol (TCP/IP) P	roperties [
eneral	
You can get IP settings assigned auto his capability. Otherwise, you need to he appropriate IP settings.	matically if your network supports ask your network administrator for
O <u>O</u> btain an IP address automatica	lly
$- \odot$ Use the following IP address: $-$	
<u>I</u> P address:	182.168.1.80
S <u>u</u> bnet mask:	255.255.0.0
Default gateway:	
Obtain DNS server address auto	matically
─⊙ Use the following DNS server ac	ldresses:
Preferred DNS server:	
<u>A</u> lternate DNS server:	
	Ad <u>v</u> anced
	OK Cance



ROADRECORDER 7006 NVR USER GUIDE

Help Windows

Each screen of the RoadRecorder 7006 NVR configuration interface includes a comprehensive help menu. The help menus explain the functionality and parameters of each field.

To access the help menu for a screen, simply click the **Help** button at the top right of the screen. The help menu appears in a new window.



Product Details

Select the information *i* icon on the top left hand corner to view the Product Details page.

The Product Details page displays factory configured identification fields as well as the status of the removable hard drive (primary), SafeStor (secondary), and SD card.

Product name: Product Name of the NVR.

Serial #: Serial number of the NVR (assigned at the factory).

MAC1 address: MAC address of the device interface of the NVR.

MAC2 address: MAC address of the wireless radio interface of the NVR.

Primary Storage Information

State: If Primary Storage is present and working then it shows "Online" state otherwise it shows "Offline" state.

Drive Size: Total size of Primary Storage drive in GB unit if it is connected with NVR.

Drive Used: Total size of Primary Storage drive used (in percentage) if it is connected with NVR.



Live View

The Live View page allows you to see the field of view of any connected camera, allowing you to focus and properly adjust the image.

The Live View requires the installation of VLC Media Player, available free from the developer.

First, select the connected cameras that you want to view. By selecting "Low" or "High" from dropdown, user can select which stream to view. Then click "**View Selected Device(s)**".

By clicking the "**View Selected Device(s)**" button, the webUI will display live feed from devices which were selected along with a link to view that particular device page under each video feed.

The web-based configurations pages for each camera can be accessed by clicking on the hyperlinked camera name below each image.

The default user name and password for Axis cameras is both **root**. The user name and password for SVC-2200 cameras is **Admin** and **1234**, respectively. The user name and password for the 45 and 46 Series cameras is **admin** and **SV123456**, respectively.

i 🕩				RR7006 Ver 509		SAFETY VISION
Live View	VIDEO Snapshot Viewer Video	o Out	ADMIN	SETTINGS	E Diagnostics	TAG EVENTS
Live V	/iew					? HELP
F: S' S'	SIP300_1 VC380_1 VC380_3	0 0 0	Low V FSIP300_2 Low V SVC30_2 Low V SVC30_4 Very Selected Develop	V LOUV V LOUV V LOUV		
Copyright © 201	15 SafetyVision, LLC. All Rights Reserved.			www.safetyvision.com		

i 🕩		RR7006 Ver 50.9		VISION'
VIDEO	ADMIN	SETTINGS	E Diagnostics	TAG EVENTS
Live View				? HELP
Frent Dear	Lee Lasanger			
Driver	Windsheld	Har Pasenge		

Snapshot Viewer

The Snapshot Viewer allows you to see still images taken from camera configured to record MJPEG.

To view a camera's snapshots, first select the camera.

As the camera produces MJPEG still images, they will be available to view in sequential order. Click on the arrow buttons forward and backward to browse through available images.





Video Out

The Video Out page configures the behavior of the video output when an optional external monitor is connected.

First, select Sequence or Static in the **Video Out Selection** field.

Sequence

Select Sequence to have the output cycle between camera views. Available cameras are listed in the **Camera** column. In the **Preference** column, select the order you want the camera view to appear in the



sequence. In the **Dwell** column, enter the amount of time, in seconds, that you want that camera view to appear.

Static

Select Static to have the output display up to four camera views full time. First, select the number of camera views that will appear on screen at once in the **Static Video**

Display Layout field. Then select from available cameras to appear in the **Camera Selection for Static Display** field.



Firmware/Config

The Firmware/Config page allows you to save configurations, format devices, update the firmware, as well as reboot the NVR.

Reboot

Click the Reboot Now button to immediately reboot the NVR and apply any saved changes. Changed configurations are not applied to the NVR until after it is rebooted.

NVR Configuration

A backup file can be created that saves all of the NVR's configuration

settings. The backup file can be applied in event these settings are lost or duplicated across multiple NVRs. To create a backup file, confirm all configuration settings are set appropriately and saved (click the Save Changes button whenever a change is made), then click the Export button. Your web browser prompts you to save the file in the location of your choice. The backup file is saved in the following format:

RR7000_NVR_[Serial number]_MM_DD_YY.xml.

Backup files are interchangable between NVRs, however unique fields such as the bus name and network information should be updated for each individual NVR.

To import a saved backup file, click the **Browse...** button. Navigate to where the appropriate file is saved and click **Open**. Confirm the appropriate file is displayed and click Import. The backup file is uploaded automatically.

NVR Firmware Update

The NVR Firmware Update function provides a convenient means of uploading a firmware file directly from an attached PC. Then upgrade the NVR's firmware:

- 1. Click the **Browse...** button. A navigation prompt appears.
- 2. Navigate to the location of the new firmware file (.tgz file).
- 3. Click Open.
- 4. Click the **Upload** button. A status bar appears as the firmware update is automatically applied.

Download NVR Firmware from Safety Vision

If the connected PC has internet access, click this link to be directed directly to Safety Vision's FTP site. Contact your Account Executive for login information.

Camera Firmware Update

Select the Camera Firmware Update option to update camera firmware through the NVR. This feature is only available for SVC-2200 Gen 2 and Gen 3, and Axis cameras.

- 1. Click the Browse... button. A navigation prompt appears.
- 2. Navigate to the location of the new firmware file.
- 3. Click Open.
- 4. Click the Upload File button. A status bar appears as the firmware update is automatically uploaded.
- 5. Once the file has been uploaded, select the camera to which firmware will be applied.
- 6. Click the Update button.

The firmware is automatically applied to the selected cameras The process will take approximately 10 minutes. Do not remove power from or unplug any cameras or the NVR. Once the firmware update is complete, the cameras will reboot automatically.

Restore Factory Default

Click the Restore NVR Factory Defaults button to automatically set all configuration options to their factory default and immediately reboot the NVR.

WARNING: Selecting this option immediately changes any previously changed settings to the factory default.

VR Firmware Undate VR Firmware t



Storage

The Storage page allows you to configure the storage device(s) of the NVR.

Primary Storage

Primary Storage Media Device: NVR will use Removable SSD for Primary Storage Media and start recording on it.

Delete file option for primary storage: This option allows user to configure the setting for deleting files from storage media and create sufficient space for recording new data.

Overwrite When Full: This option will allow user to delete older files when storage is full.

Overwrite Max Time: This option will allows user to delete file if the timestamp on the file is older than specified time. The timestamp of all files will be regularly checked at an interval of 1 hour.

No Overwrite (Stop When Full): This option will allow users to not delete any files from storage. Recording will be stopped.

Secondary Storage

Enable Safestor: By default, this is enabled and does not allow user to disable.

Secondary Storage Media: Drive label for the removable SSD

Format

Select a device, then click the Format button to immediately format it. The NVR automatically reboots after formatting the device.

WARNING: Formatting a device completely erases any saved data, including recorded video.

	RR	RR7006 Ver5.09					
VIDEO	ADMIN	SETTINGS		TAG EVENTS			
/ Config Storage Network	Date / Time Users / Passwords						
rage							
Primary Storage							
Primary Storage Media Device	Removable SSD V						
Delete file option for primary storage	Overwrite When Full						
Secondary Storage							
Enable Safestor							
Secondary Storage Media	RR7006_EF						
	Save Changes						
Format							
Select device(s) to format	Primary	Format					
		and a state					

Network Settings

The Network Settings page configures the WLAN interface and Mail server settings.

NVR Detail

NVR name: Enter the name of the NVR

Restrictions: Only alphanumeric characters are allowed with a maximum length of 15 characters. Names with "_" (underscore) are also accepted. No other special characters can be used for "NVR Name".

₽ .		RR7006 VerSag				
VIDEO	ADMIN Date / Time Users / Passwords	SETTINGS		TAG EVENTS		
twork Settings				?н		
MNVR Detail MNVR name (RR700 Main Network Interface IP address 192-16 Netmask 255.25 Gatewry 192.10 Mail Server	20 EF SafetyNet Server A Server IP address Server IP address Server Port Catoray Netmask oMG Server Default Routing	Innounce V 192 168 208 2 63542				
	Web Port					
nt © 2015 Safety/Vision, LLC. All Rights Reserved.		www.safetyvision.com				

Main Network Interface

IP Address: IP Address of the NVR for Main Network Interface connected to wireless access points.

Netmask: Netmask of NVR for Main Network Interface connected to wireless access points.

Gateway: Gateway IP Address of NVR for Main Network Interface connected to wireless access points.

Show/Hide Network Information

User will have to click on particular checkbox to view configured network related information.

Mail Server

If enabled, mail will be sent when event is triggered. If disabled, mail will not be sent on event.

Server IP Address: Mail Server IP address which is used to send e-mails if any event generated on NVR.

Username: Username which is used to login into Mail Server for sending emails regarding any event generated on NVR.

Password: Password which is used to login into Mail Server for sending emails regarding event generated on NVR.

Port Number: Contact your IT administrator for Mail Server Port Number

Mail to: Email Address to which all emails will be sent regarding any event generated on NVR.

Mail from: Email Address from which emails will be sent regarding any event generated on NVR.

LiveTrax

If enabled, LiveTrax Server will be able to receive and send packets to NVR. If disabled, LiveTrax Server Application will be stopped.

Server IP address: IP Address of the LiveTrax Server.

Send Port: Data packet is sent to LiveTrax server from this port to NVR. The valid port range is 1025 to 65535.

Receive Port: Data packet is received from LiveTrax server to this port of the NVR. The valid port range is 1025 to 65535.

Gateway: LAN IP address of router where livetrax server is connected.

Netmask: Netmask of LiveTrax server

SafetyNet Server Announce

If enabled, SafetyNet Server will be able to accept Web Requests on specified server port. If disabled, SafetyNet Server Application will be stopped.

Server IP address: IP Address of the SafetyNet Server.

Server Port: Web Request is sent to SafetyNet server to this port. The valid port range is 1025 to 65535.

Gateway: LAN IP address of router where SafetyNet server is connected.

Netmask: Netmask of SafetyNet server.

oMG Server

If enabled, oMG Server will connect with specified TCP port. If disabled, oMG Server Application will be stopped.

Server IP address: IP address of the oMG Server

Server Port: TCP port of the oMG server. The valid port range is 1 to 65535.

Default Routing

Option to configure default routing option.

Web Port

Option to configure NVR web port.

Date / Time

The Date / Time settings page configures allows modification of the NVR's time zone.

Timezone

Select the time zone the vehicle travels in most frequently.

Time Sync Priority

Use the Time Sync Priority fields to select which device has priority in providing the NVR with time stamp data. Select 1, 2, 3, or 4 (or N/A if the device is unavailable) in the **GPS**, **Manual Sync**, **COSMOS**, and **J1939** fields.



Sync RTC Date & Time

Select the **Sync with computer time** option to sync the time automatically with the connected computer, or select the **Sync with manual time** option, then click the calendar button to manually select a date and time. After confirming the time is correct, click the **Sync Now** button (the NVR reboots automatically).

Change Password

webUI Password

Change password for login into NVR system

User: Select the user for which you want to change webUI password. Several different levels of user access can be selected in the User field:

admin:

(default password: admin) - can access the entire web interface

user:

(default password: user) - can access the entire web interface except the pages under the Administration tab

viewer: (*default password: viewer*) - can only access the Live View and Change Password pages.

Admin Password: Provide current admin password in order to change password for any user

New password: Provide new password to set for selected user. New password should be 3-25 characters long

Confirm password: Provide new password for confirmation.

Change password: Web Interface login password will be changed if you have specified correct password otherwise it will give an appropriate error message. Password will be changed runtime.

These are all default passwords. It is highly recommended that the password be changed for security.

LCD Password

Change password required for initiating offload data manually or format SD Card from LCD.

Old password: Provide current password which a user needs to change.

New password: Provide new password which a user needs to change. New password should be 6 alphanumeric characters long.

Confirm password: Provide new password for confirmation.

Change password: LCD password will be changed if a user has specified correct old password otherwise it will give an appropriate error message.

The default password is "abc123". It is highly recommended that the password be changed for security.

Click Change Password to save changed entries.



Startup & Shutdown

The Startup & Shutdown page configures conditions when the NVR can automatically start and shut down.

Startup

Enable startup due to

acceleration: If enabled, acceleration above threshold value will be counted as a start-up condition and recording will be done for user-configurable duration.

Accelerometer RMS: Acceleration is one of the start-up conditions for the NVR. It will only be considered

if "Enable startup due to acceleration" field is enabled. If acceleration above the specified value is sensed, the NVR boots-up and recording starts as usual.

Restriction: Decimal values between 0.1 to 16 allowed.

Recording duration for startup due to acceleration:

If NVR is started due to vehicle acceleration, then recording will only be done for specified amount of time. NVR will gracefully shutdown after the time interval is completed.

Restriction: Recording durations can be configured from 1 to 1440 minutes.

Enable Ignition Boot and Record: If enabled, ignition above threshold value will be counted as a start-up condition and recording will be done for user-configurable duration.

Record Duration: If NVR is started due to application of ignition, then recording will compulsorily done for specified amount of time. After the interval expires and ignition if ignition is not connected, the NVR will shutdown.

Restriction: Recording durations can be configured from 1 to 1440 minutes.

Enable Temperature check Startup Delay: If enabled, Firmware will read temperature before starting the NVR. If the NVR temperature rises to threshold temperature the firmware will start immediately.

Minimum Threshold Temperature: The minimum temperature the NVR should contain for starting the NVR. If the temperature is below threshold, then the firmware will wait for some duration to allow temperature to rise.

Duration: The NVR will wait maximum of configured time for the NVR temperature to rise. If temperature of NVR is still below threshold the firmware will still start.

Restriction: Recording durations can be configured from 1 to 1440 minutes.

•		RR7006 Ver 5.0.9	VISION
VIDEO		SETTINGS	TAG EVENTS
Startup / Shutdown Audio / Video POE Settings	Sensor Settings Recording Threshold:	s GPS / GEO Fence	
Startup & Shutdown			? HELP
Startup			
Enable startup due to acceleration			
Accelerometer RMS	3.00 g		
Recording duration for startup due to acceleration	n 10 min(s)		
Enable Ignition Boot and Record			
Record Duration	1 min(s)		
Enable Temperature check Startup Delay			
Shutdown			
Continue recording after Ignition Off	×		
Record Duration	1 min(s)		
Enable Offload to Safety Net	×		
Max Transfer Duration	30 min(s)		
Safety Net Announce	Always 🗸		
Scheduled Reboot			
Enable Scheduled Reboot	×		
Days : All	🛛 Mon 🛛 Tue 🔷 Wed 🔷 Thur	Fri Sat Sun	
Time(24 Hours) : 10:00	0		
	Save Changes		
Copyright © 2015 SalehyVision, LLC. All Rights Reserved.		www.safetyvision.com	

Startup & Shutdown (cont.)

Shutdown

Continue recording after Ignition Off: If enabled, Recording continues for the specified period, even after the shutdown even is triggered, provided that vehicle power is available.

Record Duration: Specified the time up to which recording should be continued.

Restriction: Recording duration can be configured from 0 to 300 minutes.

Enable Offload to Safety Net: If this option is disabled then firmware will not send requests to SafetyNet server.

Max Transfer Duration: After all the data is captured on Primary, Primary is kept mounted for user to retrieve data.

Restriction: Host offload time limit can be configured from 0 to 360 minutes. Decimal values are not allowed.

Safety Net Announce: It has three options.

None: If this option is enabled, then web request will never be sent to SafetyNet server.

Always: If this option is enabled, then web requests will be sent to SafetyNet server after recording starts at interval of 60 seconds.

Geo fence: If this option is enabled, then web requests will be sent to SafetyNet server as per geo-fence configuration.

Scheduled Reboot

Enable Scheduled Reboot: If enabled, User can Schedule the NVR reboot time. NVR will reboot on the specified day and at a specified time.

Days: User can select the days to schedule the time for NVR reboot.

Time: User can specify a time for reboot (in 24 hour format).

Audio/Video Settings

The Audio/Video Settings page sets the number of cameras connected to the NVR in addition to their individual configurations.

Camera Discovery

Click **Discover All** to search for all available connected cameras upon initial installation and setup of the NVR. Click **Discover New** to find new cameras after cameras have been added or replaced. Click **Last Result** to automatically recover the result from the last time Discover All was used.

Add Credential

User can toggle "Add Credential" button according to their need.

Add to List: This will add camera credential to device configuration list. User can not add same credential again to device configuration list.

Limitation: Length of username and password should be less than 32 characters.

Restriction: Listed special characters may not be used: '"[]~{} (), !%^*;

Import/Export Device Configuration: User can toggle "Import/Export" button according to their need.

Import: This button will import device configuration list to NVR.This will add new credentials to current device configuration list.

Export: This button will export device configuration list.

Combine Event & Continuous: When the checkbox is checked, all event streams will get disabled. User can configure Live video stream.

Total audio + Video Device(s) (1-6): Select the number of devices you want to configure. This specifies the number of ports that must be used to connect devices to the NVR. These ports must be sequential. For example, if you select to connect 6 cameras, only ports 1 through 6 on the front panel can be used.

Enable/Disable Camera: This tag will help user to enable and disable cameras and same will be reflected in populate camera setting.

					RR	7006 Ver 5.0.9									
Shutdown	 vit	DEO Audio / Video	POE Settings	ADMIN Sensor Settings Recording	Thresholds	S GPS/GEO F	ETTINGS ence				DIAGN	DISTICS		TAG	events
io / Vid	eo							/							
Camera	Dis	covery													
Discove	r All	Discover New	Last Result	Add Credential Import/Export											
Total A	udio	+ Video Device(s): 6 V												
0															
Combin	e Ev	ent & Continuou	15 🗹					11							_
Enable															Static IP
	1	FSIP3000_1]	Continuous & Event	Main	H264 💌	3М 💌	15 🛩	6144 🗸	\checkmark		ulaw			
		FS-IP3000	~	☑ Live	Sub 🔽	H264 💌	VGA 💌		1024 🛩						
×	2	FSIP3000_2]	Z Continuous & Event	Main 🛩	H264 💌	3М 💌	15 🗸	6144 🗸	\checkmark		ulaw			
		FS-IP3000	~	☑ Live	Sub 💌	H264 💌	VGA 🛩		1024 🛩						
M	3	SVC360_1]	Continuous & Event	Main	H264 💌	2K 🛩	20 🛩	6144 💌	0 🗸	×	alaw			
		SVC-360	~	☑ Live	Sub 🔽	H264 💌	QHD 💌		1024 🔽						
M	4	SVC360_2]	Continuous & Event	Main 🛩	H264 💌	2K 🛩	20 🛩	6144 💌	0 🗸		alaw 🛩			
		SVC-360	~	🗹 Live	Sub 🖌	H264 🔽	QHD 💌		1024 💌						
×	5	SVC360_3		Continuous & Event	Main 🛩	H264 💌	2K 🗸	20 🗸	6144 💌	0 🗸	×	alaw			
		SVC-360	~	☑ Live	Sub 💌	H264 💌	QHD 💌		1024 💌						
M	6	SVC360_4]	Continuous & Event	Main 🛩	H264 💌	2K 💌	20 🛩	6144 💌	0 🗸	2	alaw 🛩			
		SVC-360	~	⊠ Live	Sub 💌	H264 💌	QHD 💌		1024 💌						
Popula	ate S	iettings:	Select C	amera V Select All FSIP3000_1 FSIP3000_2 SVC360_1	Populate										
						Save an	nd Configure						_		

Audio/Video Settings (cont.)

Device Name: Enter a unique name. A device can be uniquely identified by this name.

Restriction: Maximum allowed length for device name is 15 characters.

Type: Camera model of selected device.

Recording Type: If "Combine Event & Continuous" checkbox is checked, user will get two options for stream selection:

- Continuous & Event: Enable Continuous and Event stream. Even files can be generated from continuous data.
- Live: Enable Live video stream to view video on web interface. Select Low resolution stream (<1080p) with bitrate below 2Mbps for live looking.

If "Combine Event & Continuous" checkbox is not checked, user will get two options for stream selection:

- Continuous: Enable Continuous stream.
- Event: Enable Event Stream

Stream Type:

- Main: Main stream is a high resolution stream.
- Sub: Sub stream is a low resolution stream.

Codec: Set the codec format for the particular stream. Supported codec are MJPEG, H.264 and H.265.

Resolution: Set the resolution for the particular stream. Supported resolution caries as per the selected codec.

FPS: Set the frame speed for particular stream. Frames per second (fps) is same for both the streams. Supported FPS are 5, 10, 15, 30.

Bitrate: Sets the maximum allowed bitrate for the particular stream. Supported bitrate are 256, 512, 1024, 2048, 4096 and 6144 Kbps for H.264 and H.265 stream and 20, 40, 60 for MJPEG stream.

Rotation: Sets the video rotation of stream. Video Rotation is same for both the streams. Supported video rotation are 0 degrees, 90 degrees, 180 degrees, 270 degrees.

Audio: If audio is enabled for continuous/event recording stream then audio data is also captured and stored with video data.

Audio codec: Supported audio codecs are ulaw and alaw for camera and ulaw for Audio IO device.

Snapshot: Streams configured as mjpeg can be used for taking photos at regular intervals. To configure a stream for mjpeg codec, select mjpeg in the dropdown menu for Codec and enable the option for taking snaps.

Time Display: If this option is enabled, then time stamp will be displayed on the video data of the camera.

NTP: If this option is enabled, then camera time will be synced with the NTP server. NVR is NTP server.

Static IP: If the checkbox is checked, device will be considered as static device.

Static IP address: Assign static IP address to the device. Valid range for static ip is (182.168.1.100 to 182.168.1.149).

Populate Settings: This feature allows users to populate device settings to another or multiple devices. Configuration of selected device from the first dropdown will be saved devices from the second multi selection box. This will save all camera configurations. Cameras will be reconfigured on next boot.

PoE Settings

The PoE Settings page configures the PoE ports of the NVR.

If the checkbox is checked, PoE port is active and is receiving power. If not utilizing a PoE port, uncheck the checkbox to turn off power to selected port. By default all PoE boxes are checked.

i 🕩					RF	17006 Ver 5.0.9	SAFETY VISION
Startup / Shutdown	VIDEO Audio / Video	POE Settings	ADM Sensor Settings	IN Recording	Thresholds	SETTINGS GPS / GEO Fence	TAG EVENTS
POE Setting	gs		1.743				? HELP
POE Nu	imber	Selection					
POE1		~					
POE2		~					
POE3		~					
POE4		¥					
POE5		2					
POE6		¥					
Save Cha	nges						

Sensor Settings

The Sensor Settings page configures settings for the sensors and fault statuses.

Sensor Inputs

Name: The NVR has trigger inputs, and for easy identification these trigger inputs can be configured to have user defined names which can be entered in this field for any particular trigger input.

Restrictions: The name can contain any alphanumeric value including a single space & "_". The trigger input name can only be 15 characters max.

Threshold: The Threshold value configured here are in Volts for a particular trigger input and it is used to treat that input as either ON of OFF depending on type of Action defined for that input (ACTIVE HIGH or ACTIVE LOW).

- ACTIVE HIGH: If Trigger Action is ACTIVE HIGH and the voltage read on that particular trigger input is higher than the threshold voltage configured here, then that trigger input will be considered as ON else it would be considered as OFF.
- ACTIVE LOW: If Trigger Action is ACTIVE LOW and the voltage read on that particular trigger input is less than the threshold voltage configured here, than that trigger input will be considered as ON else it would be considered as OFF.

Restrictions: The trigger input threshold voltage can be configured to have any voltage between 1V and 30V. By default the trigger input Threshold Voltage is set to 5V and Trigger Actions is set to Metadata.

Action: The Action configured here for a particular trigger input is used for recording various types of events as described below:

Metadata: The Metadata Action is ACTIVE HIGH. If Trigger input is configured as Metadata then Event will not be recorded for that input. Trigger status (Active/ Inactive) entry will be found in Metadata Log only.

Backup Power Event: The Backup Power Event Action is ACTIVE LOW. Only Trigger seven input can be configured as Backup Power Event. Backup power event will not record audio/video streams. It will set timer for Backup Power Duration (1 to 15 Min). When time expires, NVR will shutdown. If trigger becomes active in between, timer will be aborted.

Timed Event: The Timed event Action is ACTIVE HIGH. If Trigger input is configured as Timed Event then Event



Sensor Settings (cont.)

will be recorded for (Pre + Post) Time duration for that input. Trigger status (Active/Inactive) entry will also be found in Metadata log.

Event While Active: The Event While Active Action is ACTIVE HIGH. If Trigger input is configured as Event While Active then Event will be recorded for (Pre + Active + Post) Time duration for that input. Trigger status (Active/Inactive) entry will also be found in Metadata Log.

Start Event: The Start/Stop Event Action is ACTIVE HIGH. If Trigger input is configured as Start Event then Event will be recorded for (Pre + Active) till stop event is not triggered. Trigger status (Active/Inactive) entry will also be found in Metadata Log. If one Start Event is selected than on Stop Event should also be selected.

Stop Event: The Stop Event Action is ACTIVE HIGH. If Trigger input is configured as Stop Event then all Start Event will stop recording. Trigger status (Active/Inactive) entry will also be found in Metadata Log. Stop Event can only be selected with Start Event.

Power Fail Event: The Power Failed Event is ACTIVE HIGH. Only Trigger seven input can be configured as Power Fail Event. NVR will shutdown as soon as vehicle power is failed.

When each sensor triggers, an attached optional monitor can be configured to display specific camera views.

Display: Select Single (one camera full screen), Split (two cameras), or Quad (four cameras)

Priority: Select the priority this sensor triggering has over other sensors

Dwell Time: Select the amount of time the configured camera view displays after the sensor is triggered

Cameras: Select which available camera views appear in the displayed position; the number of fields changes depending on the entry in the Display field

Enable J1939: If this option is enabled, J1939 related functionality would be enabled in the firmware else it would be disabled by default.

Control Output: Control outputs 1 and 2 of NVR will be configured as per the settings configured in Control Out 1 and Control Out 2 respectively. Currently, one can select between External Device, Fault Status or None. Selecting External Device will turn ON that Control output to switch ON the external device connected to that control out, selecting Fault Status will enable functionality to support Fault Status interface on that control output and selecting None will disable that control output.

By default, Control out 1 is selected as External Device & Control out 2 is selected as None.

Fault Status Priority

Select High, Medium, or Low in the **On**, **Slow Pulse Rate**, and **Fast Pulse Rate** fields to prioritize the fault statuses below assigned those respective signals.

Fault Status

For each fault status, select Off, On, Slow Pulse Rate, or Fast Pulse Rate signal.

Off: If this option is configured for any fault, notification will not be given on relay for that fault.

On: If this option is configured for any fault, then on occurrence of the fault the relay will be set to ON state. The relay will continue to be in this state till the fault is cleared.

Slow Pulse Rate: If this option is configured for any fault, then on occurrence of the fault the relay will toggle at a frequency of 0.5 Hz. The relay will continue to be in this state till the fault is cleared.

Fast Pulse Rate: If this option is configured for any fault, then on occurrence of the fault the relay will toggle at a frequency of 2 Hz. The relay will continue to be in this state till the fault is cleared.

- SSD Failure
- SSD Full
- Camera Failure
- GEO Violation
- Vehicle High Speed
- Vehicle High Acceleration
- Temperature
- GPS Failure

Recording

The Recording page configures file sizes and how the NVR records events.

File Size

Continuous recording file size: Size of file to be created for continuous recording.

Restrictions: File size can be configured from 50 MB to 1024 MB. Decimal values not allowed.

		RR7006 Ver 5.0.9	Visio r
VIDEO		SETTINGS	TAG EVENTS
irtup / Shutdown Audio / Video POE Settings	Sensor Settings Recording Three	holds GPS / GEO Fence	
Recording			? HELP
File Size			
Continuous recording file size	100 MB		
Event recording file size	100 MB		
Event Recorder Settings			
Pre event recording	1 min(s)		
Post event recording	_1		
Enable Event Write Protection			
Snapshot			
Capture interval	60 sec(s)		
	Save Changes		

Event recording file size: Size of file to be created for event based recording.

Restrictions: File size can be configured from 50 MB to 1024 MB. Decimal values not allowed.

Safety Vision strongly recommends retaining the default settings of 100MB.

Event Recorder Settings

When any event is triggered, audio/video data of event interval is recorded in a different file which can be extracted later. Audio/video data specific to the event is thus obtained.

Pre event recording: Audio/video data of specified minutes before the event starts are also copied to event file.

Post event recording: Audio/video data of specified minutes after the event is triggered are also copied to event file.

Enable Event Write Protection

If this option is enabled, event files will not be deleted from the storage device in case of insufficient free space.

Snapshot

Capture interval: Camera enabled for snapshots capture data at specified intervals. To enable snapshot for a particular camera, enable "Take snapshots" in individual camera configuration page.

Restrictions: Snapshot interval can be configured from 10 to 3600 sec. Decimal values are not allowed.

ROADRECORDER 7006 NVR USER GUIDE

Thresholds

Ignition

Startup minimum ignition value: Minimum ignition value, given in volts, to start NVR system. The NVR system will power on only if given ignition power is greater than configured ignition value.

Restrictions: Start-up ignition value should be always greater than shutdown ignition value.

Shutdown minimum ignition

value: Minimum ignition value to shutdown NVR system. The value is in Volts Unit. Our NVR system will

power down gracefully if given ignition power is less than configured ignition value.

Restrictions: Shutdown ignition value should be always smaller than start-up ignition value.

Accelerometer

RMS: The NVR contains a 3-axis accelerometer. Event is triggered when RMS (root, mean, square) value of all the axes is greater than specified.

Restrictions: RMS value can be configured from 0.1g to 16g.

GPS

Speed: The NVR has GPS which will provide vehicle speed. Event is triggered when vehicle speed is greater than specified.

Restrictions: Speed value can be configured from 0mph to 100mph.

i 🕩	RR		RR7006 Ver3.09		
Startup /	VIDEO		SETTINGS		TAG EVENTS
Thre	esholds				? HELP
	Ignition Startup minimum ignition value Studiown minimum ignition value Accelerometer RMS	0 ✓ Vots 6 ✓ Vots 7 2 0			
	GPS Speed	80 mph Save Changes			

GPS / GEO Fence

The GPS / GEO Fence page configures the GPS signal priority and sets up the Geo Fence feature.

GPS Priority

Use the GPS Priority fields to select which device has priority in providing the NVR with GPS data. In the **Garmin** and **OMG** fields, select 1 to give that device priority, select 2 for the secondary device.

Geo Fence

A geo fence is a defined area where a vehicle operates. When a vehicle crosses the fence, an event can be triggered or the NVR can announce itself to a SafetyNet CMS wireless network.

Get Current Location

By clicking on Get Current Location Symbol, user can redirect to current location of NVR.

To set up a geo fence:

Click the circle or polygon icon in the upper left of the map. To create a circular geo fence, click the circle, then click the map in the location of the center of the circle. Drag the mouse to increase the radius, then click again. You can further adjust the circle radius by clicking and dragging the image "handles."

To create a free-form, polygonal geo fence, click the polygon icon. Click a location on the map, then a second. A line appears. Each click creates a geo fence "post." Continue creating posts until you return to the original post, creating a complete fence. The fence can further be adjusted by clicking and dragging on the image "handles."

Only one circular geo fence can be created at once, while multiple polygonal geo fences can be created. Circular geo fences can only trigger events when the vehicle exits the fence.

For each created geo fence, select **Exit**, to trigger the geo fence effect when a vehicle leaves the defined area, or **Entry**, to trigger the geo fence effect when a vehicle enters it. Then select **Event** to trigger an event, or **SVAnnounce** to trigger a ping to be sent to a SafetyNet CMS wireless network.

Select a shape and click **Delete Selected Shape** to delete a shape and start over.



Camera

The Camera diagnostics page provides comprehensive support for technicians installing and troubleshooting the NVR's camera installation.

Camera Status

The Camera Status display shows the camera name, IP address, and operational status of each camera. Click on the camera's name or IP address (depending on if you are connected through the WAN [top] or LAN [bottom] Ethernet port) to automatically go to that camera's live view and configuration page.

SAFETY VISION i 🕩 & Ф ? HELP Camera Camera Status IP Address Camera Na 182.168.1.150 182.168.1.152 182.168.1.155 182.168.1.156 182.168.1.151 182.168.1.153 Camera Ping Status Camera: Select All Packet Size: 64 🗸 Packet Count: 10 -Go Power Rating Camera Connected on PoE1 Camera Connected on PoE2 Camera Connected on PoE3 Camera Connected on PoE4 Camera Connected on PoE5 Camera Connected on PoE6

Camera Ping Status

Select the **Packet Size** and **Packet Count**, then select an individual camera or Select All, then click **Go** to perform a camera ping test. At the end, the result is displayed below.

Power Rating

The Power Rating display shows the power each camera is drawing from the NVR.

Sensor Status

The Sensor Status diagnostics page provides assistance when installing or troubleshooting the NVR's sensors.

Select a **Refresh Interval** (the frequency at which the web page will refresh) and the **Test Duration** (in minutes), then click **Go**.

Sensor activation and their values can be observed in the display on the right.

•	RR7006 Ver	5.0.9		VISION
VIDEO ra Sensor / I/O Gos Recorder Status	ADMIN		E DIAGNOSTICS	TAG EVENTS
ensor Status		1/1/100		? HELP
Refresh Interval: 1 v seconds	Test Duration 1 Minutes	Co		
		-		
Sensor	Current Value			
MB Temperature	51 C			
Accelerometer	0.000, 0.012, 0.004, 0.007			
GPS	U Destruido adoppo Astron			
Sensor 1	Loft Turp: 0.000000 Inactivo			
Sensor 2	Dight Turn-0.000000 leasting			
Sensor 4	Door 0.000000 Inactive			
Sensor 5	Stop Arm 0 000000 Inactive			
Sensor 6	Warning Lights: 0.000000 Inactive			
Sensor 7	UPS Active 0 000000 Inactive			
Ignition	11.30 V			
Relay1	ON			
Relay2	OFF			
Vehicle Power	11.39 V			

GPS Status

The GPS Status diagnostics page provides assistance when installing or troubleshooting the NVR's GPS.

Select a **Refresh Interval** (the frequency at which the web page will refresh) and the **Test Duration** (in minutes), then click **Go**.

i 🕩		RR7006 va	r 5.0.9	VISION*
Camera	VIDEO Sensor/ IVO Gps Recorder Status	ADMIN	SETTINGS	TAG EVENTS
GPS	Status			? HELP
	Defects Internel: 1 v accorde	Test Duration: Test Minutes		
	Reiresh Interval.	Test Duration. 1 Minutes	•••	
	GPRMC	0		
	Valid	No		
	Latitude	0.000000		
	Longitude	0.000000		
	Altitude	0.000000		
	Speed	0.000000 mph		
	Heading	0.000000		
	Satellite	0		

Recorder Status

The Recorder Status page allows you to download NVR logs and diagnostic reports, as well as display the status of the removeable hard drive (primary) SafeStor (secondary).

NVR Status

The status of the NVR is displayed as Recording, Configuring, Offloading, or Safetynet Offloading.

Export Reports

To download the NVR's log or a diagnostic report, click on **USB** (to download to a USB flash

drive inserted into the front port of the NVR) or **PC** (to download to a location on an attached PC). These reports can be useful to technical support personnel when troubleshooting.

Primary Storage Information

The **State** of the drive is displayed as "Online" or "Not online". The drive's total capacity is displayed in the **Drive Size** field and the percentage of that capacity used is displayed in the **Drive Used** field.



Tag Events

The Tag Events screen allows a supervisor or other authorized user to manually and immediately trigger an event by clicking **Tag Supervisor Event**. This feature is useful in emergency situations where the web interface can be accessed wirelessly by a supervisor vehicle. (For more information regarding this feature, contact Safety Vision Technical Support.)

i 🕞	RR7006 Ver 509		№	
VIDEO	ADMIN	¢ settings	E DIAGNOSTICS	TAG EVENTS
Tag Events				? HELP
Supervisor Event				
Tag Supervisor Event				
Copyright @ 2015 Safety/Vision, LLC. All Rights Reserved.		www.safetyvision.com		

Appendix A: Specifications

SPECIFICATIONS		
Part No. 7006-NVR		
Operating System	Embeded Real Time Linux	
Audio/Video Inputs	Audio: 6 channels (network RJ45 connector) Video: 6 channels (network RJ45 connector) *10 channels with external PoE switch	
Audio/Video Outputs	N/A	
Audio/Video Compression	G.711 / H.264	
Resolution	$\begin{array}{c} 2048\times2048,1920\times1080\ (1080p),1280\times720\ (720p),\\ 720\times480\ (D1),352\times240\ (CIF) \end{array}$	
Frame Rate	30 FPS (all channels, all resolutions)	
Image Quality (bit rate)	256 KB/sec - 6 MB/sec	
Storage	$1 \times$ SATA II 1 TB SSD (2 TB max)	
Recording Mode	Continuous (dual stream) / Scheduled / Event (sensor trigger, speed, acceleration, video loss, temperature), Pre/Post Recording	
Pre-Event Recording	Configurable up to 5 minutes	
Post-Event Recording	Configurable up to 10 minutes	
Ethernet	Gigabit Ethernet; 2 \times RJ45; 12 \times 100 mb PoE	
GPS (External Antenna Required)	Location tracking, speed detection, and sync time	
Interfaces	$1 \times RS232$, $1 \times USB$, $1 \times micro-USB$, $1 \times CAN$	
Accelerometer	3-Axis, 0.1 G resolution	
Sensors	7 inputs plus ignition / 2 outputs (dry contact)	
Power Input	6 ~ 36V DC	
Power Consumption	80W (max)	
Environmental Control	Integrated cooling fan	
Operating Temperature	32° F ~155° F (0°C ~ 70° C)	
Dimensions (w \times h \times d)	7.48 × 2.79 × 7.60 in (189.99 × 70.87 × 193.04 mm)	
Certifications	J1939	
Encryption	Hardware AES, DES, 3DES	

Appendix B: Dimensions



Appendix C: Axis Device Configuration

The RoadRecorder 7006 NVR supports both the Safety Vision SVC-2200 series cameras in addition to Axis network cameras. Configuration is identical except Axis cameras must be configured with the login and password both set to root. Use the following procedure to properly configure an Axis network camera:

- 1. Connect both a PC and the Axis device to a power over Ethernet (PoE) switch and ensure the PC is on and the PoE switch is receiving power. Allow the camera enough time to start up (1 to 2 minutes).
- Configure a static IP address on the PC to 192.168.0.100.
 In Windows, open Network Connections.
 Right-click the LAN connection and select *Properties*. In the list of items, select *Internet Protocol (TCP/IP)* and then click *Properties*.
- On the PC, in an internet browser, navigate to 192.168.0.90. The camera's login screen appears.
- 4. Enter root in the Password and Confirm password fields.
- Click OK. A prompt appears requesting a login with the newly set password.
- 6. Enter **root** for both the username and password.
- Click OK. A prompt screen appears requesting the power

line frequency in your area.

8. Ensure the appropriate Hz value is entered in the field and click **OK**. The Axis camera is now configured to operate with the RoadRecorder 7006 NVR.

For Axis audio devices, follow the steps above, then additionally ensure that the **Encoding** field is set to **G711 μ-law** under **Audio Settings**, as shown in the screenshot.

System Options/Users - AXIS ×
C $\leftrightarrow \rightarrow \mathbb{C}$ 192.168.0.90/pwdroot/pwdRoot.shtml



• C 182.168.1.1	01/operator/aud	io.shtml?id=10		
AXISA AXI	S P8221 I/C	Audio Module Live View Setup Help		
- Audio	Audio Set	tings 💡		
Audio Settings	Audio Channels	5		
Audio Clips	Audio mode:	Simplex - Network IO Audio Module microphone only 💌		
Ports & Devices	Audio Input			
	Port:	Audio 1 💌		
Live View Config	Source:	Microphone 💌		
▶ Events	Enable micro should be off.	Enable microphone power. If your microphone is dynamic or battery powered, this should be off.		
System Options	Enable 48V n	nicrophone phantom power.		
About	🗹 Enable micro	phone level LED		
	Input gain:	0 💌 dB (0 = medium default level)		
	Encoding:	G711 µ-law 💌		
	Sample rate:	8 💌 kHz		
	Bit rate:	64 💟 kbits/s		
	Alarm level:	50 [0100] %		
	Audio Output			
	Output gain:	0 💌 dB (0 = medium default level)		
	Enable speaker amplifier (Audio 2)			
		Save Reset		

Appendix D: GPS Coordinate Conversion

The Threshold Settings page of the Web Configuration requires GPS coordinates be entered in degrees, minutes, and decimal minutes format. However, GPS coordinates are typically displayed in decimal degree format. Use the following procedure to determine the required GPS coordinates and convert them to the required format:

- Enter the address of the required GPS location in Google Maps. Google Maps can be accessed at www. google.com/maps Safety Vision's headquarters is used as an example.
- 2. Confirm the appropriate address appears on the map as a red balloon marker.
- 3. Right click on the red balloon marker.
- Select the What's here? option. The longitude and latitude appear, separated by a comma, in the Google Maps search bar. In the example, Safety Vision's coordinates are displayed as 29.857934,-95.562623.
- 5. Use the following formula to convert these decimal degree format coordinates to the degrees, minutes, and decimal minutes:
 (DD x 100) + (0.DDDDDD x 60)
 In the example, the longitude 29.857934
 is converted as follows:
 (29 x 100) + (0.857934 x 60)
 = 2900 + 51.47604
 = 2951.47604
- 6. Apply the calculated GPS coordinate to the appropriate field in the Threshold Settings page of the Web Configuration.





FCC Compliance Statement

NOTE

This device has been tested and found to comply with the limits for a *Class A digital device*, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference at his own expense.

CAUTION

Any changes or modifications in construction of this device which are not expressly approved by the party responsible for the compliance could void the user's authority to operate the equipment.

CORPORATE HEADQUARTERS

6100 W. Sam Houston Pkwy. N. Houston, TX 77041-5113

Main: 713.896.6600 Toll Free: 800.880.8855 Fax: 713.896.6640 www.safetyvision.com

